



NEW VINTAGE USA
2415 BURDETTE
FERNDAL, MI 48220
248.2594964 PHONE
248.656.8291 FAX
info@newvintageusa.com
www.newvintageusa.com

70-72 CHEVELLE SS PANEL ASSY

Thank You for choosing NVU for your gauge solution company. This package is designed to install any NVU 70-72 Chevelle gauge package into your existing (new or original) dash carrier. It is designed to be adjustable to fit any panel variation and ensure a proper, professional fit.

**this kit re-uses your stock lens, the gauges are not furnished with lenses.

1. Remove cluster from vehicle, remove all original items from back.
2. Place 3-3/8" gauges in spacer plate, loosely tighten back clamps as shown. Make sure engraved area marked BACK reads from the back (facing you during installation)
3. Place backing plate on rear of panel. Secure perimeter screws to attach to back.
4. Loosely tighten the adjustment #8x1" screws to push the middle panel with gauges against the front of the panel. Look at the front and adjust/align gauges as needed. The gauges can be in any of the holes to suit your taste. Once you are satisfied, tighten back clamps and adjustment screws.
5. Insert red and blue LED holders in appropriate light holes in lower portion
6. Insert proper number of spacers between the gauge and back plate as shown on right, insert in panel, tighten and adjust as needed
7. Wire turn signals and lamps as needed.
8. Fuel gauge is wired per instructions/markings on back. The fuel gauge is a 0-90 GM factory match
9. Wire gauges according to instruction booklet
10. Re-install carrier, lens, etc and enjoy



Water temp 3 spacers



Oil press 1 spacer

Volts 2 spacers

